




Overall Dimensions - Model: 1034D (E26)




## Contents (not to scale)


Please double check all components are present and quantities are correct before beginning assembly



x1  
Top Panel Assembly  
(Power cable not shown)



x20  
Tapered  
Felt Panels




x1  
2.1m cable  
(82 in)




x40 (+5)  
Small Ratchet Rivets  
(13mm / .5 in)



x40 (+5)  
Large Ratchet Rivets  
(19mm / .74in)





x1  
Cone Gripper  
with Base




x2  
Folded  
Cardboard  
Pillars

## Step 1 - Top Panel Ratchet Rivet Assembly



Insert Large Ratchet Rivets (19mm) in all holes around edge.


(power cord and suspension wires not shown)



---

## Step 2 - Pop out side panel plugs


---



Push out the 4 plugs per panel to make way for the plastic clips.

## Step 3 - Top Panel to Side Panel Assembly


Assemble on a large clean surface or on floor.




---

Step 4 - Top Panel to Side Panel Assembly Continued

---



Cross Section Detail View of Top Panels overlapping.




---

## Step 5 - Lifting into shape


---

Use suspension cable to lift the Hush Mini approximately 400mm (16 in) from the floor/surface.

The panels will begin to fall into their natural shape.




Use the folded cardboard pillar that was in the box (or similar-sized table) to prop it up.



## Step 6A - Weaving of Panels - Exploded Detail

Bold Lines indicate the 'Ear' that sits on the outside of the Hush Mini.  
This weaving pattern is essential to lock the shape together




Once two panels are woven together, use two of the shorter Ratchet Rivets (13 mm) to lock them together.



---

## Step 6A - Weaving of Panels - Finished Detail

---





Bold Lines indicate the 'Ear' that sits on the outside of the Hush Mini.  
This weaving pattern is essential to lock the shape together

## Step 7 - Height Adjustment and Levelling


### Ceiling Mounting Point.

If installing into wood use a countersunk timber screw (not supplied) to affix cone grip to ceiling.


If installing into concrete use countersunk anchor bolt (not supplied) to affix cone grip to ceiling.



To shorten wire:  
Pull cable through hole  
in side of gripper point




To lengthen wire:  
Depress cylinder at top  
of gripper point and pull  
wire out



---


Step 8 - Electrics with Hanging Ceiling

---




Appendix 1: Top Panel Sub Assembly

Aluminium Disk




Felt Panel



3 x 12mm Screws



Exploded View



Assembled View