



Overall Dimensions - Model: 1034-B (240V)




Contents (not to scale)


Please double check all components are present and quantities are correct before beginning assembly



x1
Top Panel Assembly
Mini size: 280 mm
(Power cable not shown)



x20
Tapered
Felt Panels
Mini size: 650mm long




x1
2.1m cable




x40 (+5)
Small Ratchet Rivets
(13mm)




x40 (+5)
Large Ratchet Rivets
(9mm)



x1
Cone Gripper
with Base





x1
LED Driver
(PCD-16-700B)




x2
Folded
Cardboard
Pillars

Step 1 - Top Panel Ratchet Rivet Assembly




Insert Large Ratchet Rivets (19mm) in all holes around edge.

(power cord and suspension wires not shown)




Step 2 - Pop out side panel plugs




Push out the 4 plugs per panel to make way for the plastic clips.

Step 3 - Top Panel to Side Panel Assembly


Assemble on a large clean surface or on floor.



Step 4 - Top Panel to Side Panel Assembly Continued




Cross Section Detail View of Top Panels overlapping.




Step 5 - Lifting into shape

Use suspension cable to lift the Hush Mini approximately 400mm from the floor/surface.

The panels will begin to fall into their natural shape.




Use the folded cardboard pillar that was in the box (or similar-sized table) to prop it up.




Step 6A - Weaving of Panels - Exploded Detail

Bold Lines indicate the 'Ear' that sits on the outside of the Hush Mini.
This weaving pattern is essential to lock the shape together



Once two panels are woven together, use two of the shorter Ratchet Rivets (13 mm) to lock them together.

Step 6A - Weaving of Panels - Finished Detail





Bold Lines indicate the 'Ear' that sits on the outside of the Hush Mini.
This weaving pattern is essential to lock the shape together

Step 7 - Height Adjustment and Levelling


Ceiling Mounting Point.

If installing into wood use a countersunk timber screw (not supplied) to affix cone grip to ceiling.


If installing into concrete use countersunk anchor bolt (not supplied) to affix cone grip to ceiling.




To shorten wire:
Pull cable through hole
in side of gripper point



To lengthen wire:
Depress cylinder at top
of gripper point and pull
wire out




Step 8 - Electrics, Suggested LED driver placement with hanging ceiling




Appendix 1: LED Driver Diagram

MEANWELL 16W Single Output C Dimmable LED Power Supply
(PCD-16-700B)



IMPORTANT:
THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE
WITH THE APPLICABLE INSTALLATION CODE BY A
PERSON FAMILIAR WITH THE CONSTRUCTION AND
OPERATION OF THE PRODUCT AND THE HAZARDS
INVOLVED

Appendix 2: Access to LED Lights for maintenance




Appendix 3: Top Panel Sub Assembly

Aluminium Disk
(LEDs on underside)


Plastic Spacer Disk

Felt Panel

3 x 12mm Screws



Exploded View



Assembled View