

Overall Dimensions - Model: 1018-D (E26)





#### Contents (not to scale)

Please double check all components are present and quantities are correct before beginning assembly






x2 3m Cable




x48 (+5) Small Ratchet Rivets (13mm)




x48 (+5) Large Ratchet Rivets (19mm)



x2 Cone Gripper without Base




x2 Cone Gripper with Base




x2 Folded Cardboard Pillars




#### Step 1 - Top Panel Ratchet Rivet Assembly






Insert Large Ratchet Rivets (19mm) in all holes around edge.



Step 2 - Pop out side panel plugs


Push out the 4 plugs per panel to make way for the plastic clips.






#### Step 3 - Top Panel to Side Panel Assembly

Assemble on a large clean surface or on floor.







## Step 4 - Top Panel to Side Panel Assembly Continued



## Step 4 - Top Panel to Side Panel Assembly Continued




Cross Section Detail View of Top Panels overlapping.




## **PLN** GROUP

#### Step 5 - Lifting into shape




## IMPORTANT: ENSURE YOU ONLY USE THE 2x STEEL CABLES TO





## Step 6A - Weaving of Panels - Exploded Detail

Bold Lines indicate the 'Ear' that sits on the outside of the Hush Round. This weaving pattern is essential to lock the shape together




Once two panels are woven together, use two of the shorter Ratchet Rivets (13mm) to lock them together

# **PLN** GROUP

## Step 6A - Weaving of Panels - Finished Detail






Bold Lines indicate the 'Ear' that sits on the outside of the Hush Oval. This weaving pattern is essential to lock the shape together


## **PLN** GROUP

## Step 7 - Height Adjustment and Levelling





Step 8 - Electrics, Suggested LED driver placement with hanging ceiling



## Appendix: Top Panel Sub Assembly

