


HUSH OVAL

Designed by David Trubridge


PLN GROUP

Overall Dimensions - Model: 1018-C (Hood)



Contents (not to scale)


Please double check all components are present and quantities are correct before beginning assembly



x1
Top Panel Assembly
(Power cables not shown)

x8
Straight
Felt Panels

x16
Tapered
Felt Panels




x2
3m Cable




x48 (+5)
Small Ratchet
Rivets (13mm)




x48 (+5)
Large Ratchet
Rivets (19mm)



x2
Cone Gripper
without Base





x2
Cone Gripper
with Base




x2
Folded
Cardboard
Pillars

Step 1 - Top Panel Ratchet Rivet Assembly

Screw on x2 Cone Grippers
(without bases)
onto base
already attached to top
panel assembly





Insert Large Ratchet Rivets (19mm) in all holes around edge.




Step 2 - Pop out side panel plugs

Push out the 4 plugs per panel to make way for the plastic clips.




Step 3 - Top Panel to Side Panel Assembly

Assemble on a large clean surface or on floor.




Step 4 - Top Panel to Side Panel Assembly Continued



Tuck Last panel under First panel and clip together with Large Ratchet Rivet (19mm)



Cross Section Detail View of Top Panels overlapping.



Step 5 - Lifting into shape


Insert cables into Gripper Cones and use it to lift the Hush Oval approximately 600mm from the floor/surface.

The panels will begin to fall into their natural shape.




IMPORTANT:
ENSURE YOU ONLY USE THE 2x
STEEL CABLES TO
LIFT THE OVAL HUSH HOOD

Use the folded cardboard pillar that was in the box to prop it up.




Step 6A - Weaving of Panels - Exploded Detail

Bold Lines indicate the 'Ear' that sits on the outside of the Hush Round.
This weaving pattern is essential to lock the shape together



Once two panels are woven together, use two of the shorter Ratchet Rivets (13mm) to lock them together

Step 6A - Weaving of Panels - Finished Detail




Bold Lines indicate the 'Ear' that sits on the outside of the Hush Oval.
This weaving pattern is essential to lock the shape together

Step 7 - Height Adjustment and Levelling

Ceiling Mounting Point.

If installing into wood use a countersunk timber screw (not supplied) to affix cone grip to ceiling.

If installing into concrete use countersunk anchor bolt (not supplied) to affix cone grips to ceiling.



To Raise:
Pull cable through hole
in side of Gripper Cone


To Lower:
Depress cylinder at top of
Gripper Cone

Step 8 - Suggested placement with hanging ceiling


Concrete

Hung Ceiling

**IMPORTANT:
WEIGHT OF LIGHT SHOULD BE
SUPPORTED BY SUSPENSION
WIRES AND NOT THE POWER
CORD**



Appendix: Top Panel Sub Assembly



2x Gripper Cones
2x M5 20mm Screws

Aluminium Panel

2x Washers
2x Cap Nuts

Felt Panel

12 x 12mm Screws

Exploded View